FLY KILLER KOVER INSTRUCTIONS PATENTS 7,950,351

- 1. ASSEMBLE, FOLLOWING ENCLOSED DIAGRAM DRAWINGS. FLIP UNIT OVER AND SATURATE KOVER WITH INSECTICIDE.
- 2. WE RECOMMEND GORDONS BACKRUBBER & POUR ON. THIS IS A RTU (READY TO USE) .250% PERMETHRIN. SAFE ON BEEF AND DAIRY. AVAILABLE AT TSC STORES. KOVER AND ATTACHED RESERVOIR MUST ROTATE FREELY. FITS REALLY SLOPPY ON FEEDER. THIS ENHANCES LIFE OF KOVER AND FEEDER.
- 3. ADD MINERAL. DO NOT FILL OVER HALF FULL. IF USING BLOCK MINERAL, BREAK INTO SOFTBALL SIZE. UNIT MUST BE ONLY SOURCE FOR MINERAL. IT MAY TAKE A WEEK FOR LIVESTOCK TO DISCOVER MINERAL.
- 4. WAIT A WEEK TO FILL RESERVOIR. INSECTICIDE WICKS OUT OVERNIGHT. FILL WEEKLY OR AS NEEDED. IF YOU GET EXCESSIVE DRIPPAGE OFF THE OUTER RIM ONTO THE GROUND, DON'T FILL AS OFTEN OR ONLY FILL HALF FULL.
- 5. WHEN ADDING MINERAL, USE PULL STRIP TO RAISE KOVER FOR ACCESSABILITY TO FEEDER.
- 6. FEEDER SHOULD NOT BE STAKED DOWN. IF NEEDED, DRIVE STAKE INTO GROUND AND PLACE FEEDER OVER STAKE.
- 7. IF YOU PURCHASED A KIT AND CAN'T ADAPT TO YOUR FEEDER, YOU WILL HAVE TO DRILL A HALF INCH HOLE DOWN THROUGH THE CENTER OF THE MOUNTING NUT. IF YOU NEED HELP CALL 1 785 363 2655.
- 8. IF YOU PREPARE YOUR INSECTICIDE, USE A FOOD GRADE MINERAL OIL AS A DILUTEANT. MANUFACTURER 1 800 232 3639 FOR DRIP OIL. DO NOT USE WATER, DIESEL FUEL OR VEGETABLE OIL.
- 9. END OF FLY SEASON, REMOVE FELT KOVER AND REPLACE WITH RUBBER COVER. STORE KOVER FLAT WITH FELT SIDE DOWN
- 10. IF KOVER EVER STOPS WICKING, REMOVE AND POWER WASH.

NEVER USE A GRUBICIDE OR SYSTEMIC INSECTICIDE

WARRANTY

WE WILL REPLACE ANY BROKEN OR DEFECTIVE PARTS WITHIN ONE YEAR FROM DATE OF PURCHASE, WITH VERIFABLE DAMAGE REPORT. IF NOT SATISIFIED WITH UNIT, RETURN TO MANUFACTURER WITHIN 30 DAYS OF PURCHASE, IN NEW CONDITION, AND WE WILL RETURN YOUR PURCHASE PRICE.

MANUFACTURER AND DISTRIBUTOR

F AND B MANN PRODUCTS LLC PO BOX 274 WATERVILLE, KANSAS 66548 1 785 363 2655 FAX 1 785 363 2117 E-MAIL FLYKILLERKOVER@HOTMAIL.COM

To Assemble---Remove all parts from thrbbveaded stem. Lock vice grip under welded on washer and use 3/4" wrench to tighten nut inside reservoir <u>but don't use excessive</u> force.

Kover and assembled reservoir fit loosely on feeder.

Once assembled---place unit on ground with felt side upward and saturate felt with insecticide. Flip unit upright and add 50# of mineral. Wait a week after livestock start consuming mineral to fill reservoir with insecticide and fill weekly thereafter.

Lice problem use the Flykiller Kover for control.

