

HOW TO USE

Ranchmate®'s core products are preformed connectors called TwistSplices and fencing terminations called TwistEnds. These instructions show how easy it is to use Ranchmate products. Your fence construction or repair will be strong and it will last for generations.

1 Pull the fence wire together so that the ends are not more than 1/16 inch apart. Do not overlap the fence wire. Remove barbs as needed. Note the color mark on the splice.



2 Begin at the color mark and twist the first splice of the set onto the wire. Twist the splice until it snaps securely, holding the wire ends together.



3 Align the second leg of the splice, using the color crossover mark as the center, and begin twisting it into the first leg of the splice.



4 Continue twisting both ends of the splice legs until they are in place and securely holding the fence wire ends.



5 Roll your thumbs over the ends to make sure that all ends of the splice are snapped securely into place.



6 And that's it! Your Ranchmate TwistSplice is complete and your repair is strong and durable.

