



INSTRUCTIONS

- Step 1: Unlock lock with key if it is not already unlocked. Keys may be removed at this point as they are not necessary to push the plunger of the lock.
- Step 2: Pull each end of the locking device apart, but not so far apart that the two ends disengage.
- Step 3: Place one end of the locking device around the flange of the gooseneck coupler.
- Step 4: Push the other end of the locking device, which is **not** around the flange, while holding the other end which **is** around the flange, toward the opposite flange so that it goes over it and allows the locking device to cover the coupler. Continue pushing until you are unable to push the ends together.
- Step 5: You may now depress the button of the plunger lock. Some adjusting of the ends may be necessary to allow the locking device to operate. **However**, this should be minimal.

Care and Maintenance

- 1) Every few months a drop of light weight oil needs to be applied to the plunger lock so that it will continue to work well and so that the inner locking parts are lubricated. Do this by applying oil on the key hole and the top of the plunger area.
- 2) From time to time it may be necessary to keep the sides of the locking device lubricated so that it will slide together with ease. Use a grease or petroleum jelly on the ears of the small slide piece.

Questions or problems should be directed to We-Lock Industries, 417/864-3688, 9 a.m. - 4 p.m. CST.