


Nail Grinder

Model 78129-101



Oster

© 2002 Sunbeam Products, Inc.
All Rights Reserved.

Oster® is a registered trademark of
Sunbeam Products, Inc.

IMPORTANT SAFEGUARDS

SAVE THESE INSTRUCTIONS


CAUTION

Please read and apply the following safety regulations thoroughly before starting to work with the machine, thereby protecting yourself and others.

- Keep the working area clean and tidy.
- Do not use electrical tools in rain, under wet conditions or in the vicinity of flammable liquids or gases.
- Keep children away from the working area.
- Always wear goggles.
- Wear a breathing mask under dusty working conditions.
- Store unused tools in a locked room out of the reach of children.
- Before starting to work check the machine for any obvious faults, replace damaged parts.
- Do not overload the machine.
- Do not carry the tool by the power cord.
- Protect the power cable against heat and sharp edges.
- Replace blunt tools.
- Clean the machine after each use by cleaning the vent areas with a stiff bristle brush to remove all debris. Brush all debris from around the collet and clamping jaw. Do not immerse the tool in any liquid for any purpose. Use only a soft dry cloth to clean the housing.
- Always disconnect the power cable if the machine is not in use, when changing tools or in case of repairs.
- Any repairs to the electrical system must be made by either OsterDirect® or an Oster® Authorized Service Center.
- Use only accessories and spare parts which are mentioned in these instructions or are recommended by the manufacturer.

- If the power cord is damaged it must be replaced by either OsterDirect® or an Oster® Authorized Service Center.
- Prior to turning on this appliance, always check the grinding stone or wheel attachment to insure that it is properly secured in the chuck of the grinder.
- Use only with Class 2 transformer OH-67025DT


PARTS



HOW TO USE THIS TOOL

- Turn on and hold near animal to evaluate reaction to grinder noise. Follow this by picking up each of the animal's legs and rubbing the housing across the animal's paws.
- Push hair back and away from nail. Avoid touching the animal's coat with grinder in order to prevent tangling and injury.
- Begin grinding from the bottom of the nail working towards the tip to insure a smooth edge. Gently run grinding stone on each nail, holding each toe securely between your fingers as you grind each nail. Do not apply too much pressure. This device works because of its high speed. If you apply too much pressure the device will stop running causing overheating and damage to the unit.
- It is important to have your pet restrained in order to prevent it from trying to chew on the tool or cord.


HOW TO HOLD THIS TOOL



OPERATION — CLAMPING, CHANGING TOOLS

ATTENTION


- Pull the main plug out before changing tools.
- Never press the locking pin while the machine is running.
- Turn the spigot nut 1 lightly while pressing the locking pin until the pin engages.
- Open the clamping jaw and change the tool.
- Clamp all tools as short as possible. Shafts which stick out too far will easily bend causing the machine to vibrate.



Clamping Jaw

POWER SUPPLY

- Push the non-reversible plug into the power unit.
- In case of overloading the power unit will switch off automatically.
- Never use any other transformer.



SPECIFICATION

Length : 215mm
Weight : 245g
Power : 45W
Motor Speed : 0 - 20,000 rpm
Voltage : 18V
Rated Current : 1A

Oster

© 2002 Sunbeam Products, Inc. All Rights Reserved.