

# Foal Resuscitator Instructions

One person can operate the McCulloch Medical™ Aspirator/Resuscitator using a simple push/pull action. Valves at each end do all the work. On the wide end there are two one-way induction valves for aspiration. On the narrow end there is one two-way valve for resuscitation.

## Aspiration

- Attach the aspirator mask on the wide end and place over the muzzle.
- One-way induction valves draw air in on the out-stroke.
- A vacuum is created when the unit is pumped to remove mucus or fluids that may be blocking the airway.
- Tilt head back to open airway.
- Four or five pumps will draw the mucus or fluids into the aspirator mask.
- Remove the aspirator mask from the pump and follow resuscitation instructions.

## Resuscitation

- Attach the resuscitator mask to the small end of the unit and place over the muzzle.
- The one-way valve will induct air into the unit on the out-stroke and drive it down through the two-way valve into the lungs on the in-stroke.
- The two-way valve then opens and allows oxygen-depleted air to escape to the side and NOT reintroduce oxygen-depleted air.
- Resuscitator should be pumped every 5 to 10 seconds.
- Breathing should be stimulated with as few as 5 to 10 pumps. Check for breathing every few pumps.
- If not breathing after 4 to 5 pumps, turn the foal over and repeat. This will allow the lung previously closer to the ground and weighed-down by internal organs to inflate more easily.
- Continue while heartbeat remains.

