

EasyShoe Versa Grip - Front Size Chart

Size	Width in mm	Length in mm	Thickness
102F	96-102mm	113mm	16mm
106F	100-106mm	117mm	16mm
110F	104-110mm	122mm	16mm
114F	108-114mm	126mm	16.2mm
118F	112-118mm	131mm	16.2mm
122F	116-122mm	135mm	16.2mm
126F	120-126mm	139mm	16.2mm
130F	124-130mm	143mm	16.2mm
134F	128-134mm	148mm	16.2mm
138F	132-138mm	153mm	16.7mm
142F	136-142mm	157mm	16.7mm
146F	140-146mm	161mm	16.7mm
150F	144-150mm	166mm	17.2mm
154F	148-154mm	170mm	17.2mm
158F	152-158mm	175mm	17.2mm
162F	156-162mm	179mm	17.8mm
166F	160-166mm	183mm	17.8mm
170F	164-170mm	188mm	17.8mm

EasyShoe Versa Grip - Hind Size Chart

Size	Width in mm	Length in mm	Thickness
102H	96-102mm	118mm	16mm
106H	100-106mm	122mm	16mm
110H	104-110mm	127mm	16mm
114H	108-114mm	131mm	16.2mm
118H	112-118mm	136mm	16.2mm
122H	116-122mm	140mm	16.2mm
126H	120-126mm	145mm	16.2mm
130H	124-130mm	149mm	16.2mm
134H	128-134mm	154mm	16.2mm
138H	132-138mm	159mm	16.7mm
142H	136-142mm	163mm	16.7mm
146H	140-146mm	168mm	16.7mm
150H	144-150mm	173mm	17.2mm
154H	148-154mm	177mm	17.2mm
158H	152-158mm	182mm	17.2mm
162H	156-162mm	186mm	17.8mm
166H	160-166mm	191mm	17.8mm
170H	164-170mm	195mm	17.8mm

Ideally, your horse's hoof measurements should fall on the lower end of the range of width measurements, and be no longer than the length measurement listed next to each shoe size. For example, a hoof that would fit well into the 110F would measure 104-106mm wide and less than 122mm long. If necessary, it is simple to trim down any extra width or length of the shoe to customize the fit for your horse.