

# KNEE BOOT SIZE CHART

The measurements are a guide to finding the correct size.


- Measure in cm by using a soft measuring tape.
- Make sure that your horse is in a relaxed state and is standing properly.
- Follow the measuring instructions, and choose your horse's size from the table.

Measuring instructions:

Measure the circumference of your horse's leg as illustrated in the image. Determine your horse's size by comparing the measurements in the chart to those of your horse's legs where the boots should sit.

**A** Measure the circumference above the knee.

**B** Measure the circumference below the knee.



SIZE OF BOOT	S	M	L	XL
<b>A</b> Circumference Above	26 - 30	28 - 32	30 - 34	32 - 37
<b>B</b> Circumference Below	21 - 26	24 - 29	26 - 31	28 - 33

Art.No. 2035 & 2036

Measurements in cm