

"Captain Canada"

Now Uses

Super Comfort Iron Pads

"No matter what your discipline, greatly reduce your chances of losing an iron with the comfort and security of Super Comfort Iron Pads"

Jan D Miller

WWW.SUPERCOMFORTIRONPADS.COM



United States of America and Foreign Patent # D-458,420

- Pads stay firmly in place
- Helps keep heels down
- Improves body and leg position
- Virtually indestructible patented rubber pads

STANDARD
FITS IRON SIZES
4¹/₄" 4¹/₂" 4³/₄"

★ Simple Instructional tips on back

Made in U.S.A.

EASILY ATTACHES TO YOUR OWN IRONS

READ SIMPLE INSTRUCTIONS — ATTACH GENTLY —

- ★ No need to take irons off of your saddle
- ★ If you've purchased the correct size pad for your irons, and attached them properly, **Your Pads Won't Budge!**

ALL IRON SIZES AVAILABLE

STANDARD
FITS IRON SIZES
4¹/₄" 4¹/₂" 4³/₄"

SMALL
FITS IRON SIZES
4" OR THIN RACING IRONS

POLO PADS
SMALL POLO IRONS
LARGE POLO IRONS

- ★ **Take your time** - Don't cut tie ends off until you do this test; Try to turn your pads in a complete circle around the base of your iron. If your pad is still moving, you need to squeeze pad ends together while you gently continue tightening your ties.

NOTE: Some pad ends, **may** need to overlap a tiny bit before they're firmly in place. **Some** pad ends may not even touch. - or - If you're convinced your pads are too big for your irons, you can:

1. Trim edges slightly with sharp scissors.
2. Return pads for a smaller size.

DIRECTIONS



1. REMOVE all rubber inserts and metal graters from your irons. Center pad, on the inside base of the iron, nylon side down.



2. Wrap ends of pad toward bottom of iron. Turn iron up side down and make sure the holes on both ends of pad are aligned. With the first plastic tie, start in the center, with the RIDGED SIDE UP and the head pointing down. Thread through the center hole directly across to the corresponding hole on other end. Insert tie into flat side of head and loosely tighten. This tie will hold the pad in place while the others are inserted in the same manner.



3. Squeeze pad ends together and begin tightening GENTLY. Turn your wrist BACK and forth in a left to right motion, gradually pulling tie slack tight. Try to keep tie heads in a straight line. Continue process until all ties are tight.



★ **Manufacturer Suggests** changing ties every other year.

4. Check to see if your pad is firmly in place. If so, proceed to cut ties smoothly off.